


SSP-S200 series

Reflective bin-picking
light curtain sensor



- **Retroreflective and Diffuse reflective mode switching**

It is possible to switch between Retroreflective and Diffuse reflective modes by flipping an Inner switch. You can select either Retroreflective or Diffuse reflective mode depending on the detecting distance for use.

- **Super thin body at only 13mm thick with sturdy metal case**

The metal case protects against impacts that may occur when an item, which you are taking out from a shelf, hits the case. Also, its space-saving thinness means the sensor does not become an obstacle during work.

- **Easy-to-see large Job indicator**

On the side of the body, there are two large-sized, high-intensity green LED Job indicators which are easy to see.

- **NPN/PNP dual output**

You can select either NPN or PNP output with an inner switch of the sensor, which will contribute to reducing your stock of sensors.

- **Fault indicator**

If you take out the wrong item from a shelf, red lights of the Fault indicator flash on and off, letting you know the item is wrong.

- **Initial sensitivity setting function**

When you turn on the power after selecting either Retroreflective or Diffuse reflective mode, the optimal sensitivity is automatically set by the initial sensitivity setting function.

Type


| Detection method | Detecting distance | Detecting width | Model | Number of beams | Operation mode | Output mode | Connection |
|--------------------|--------------------|-----------------|---------------------|-----------------|---------------------------------------|--|----------------------|
| Diffuse reflective | 700mm | 100mm | SSP-S204R | 4 | Normal Open or Normal Close switching | Open collector output NPN/PNP switching | Cable |
| | | 225mm | SSP-S208R | 8 | | | |
| Retroreflective | 2m | 100mm | SSP-S204R-PJ | 4 | | | Cable with connector |
| | | 225mm | SSP-S208R-PJ | 8 | | | |

Reflectors and mounting brackets are optional accessories.

Optional Parts

| Type | Model | Note |
|----------------------------|------------------|---|
| Dedicated mounting bracket | SSP-B1 | Flat type |
| | SSP-B2 | L-shape type |
| Cable with connector | FAC-D4R2S | Straight type |
| | FAC-D4R2L | Angle type |
| | FAC-D4R5S | Straight type |
| | FAC-D4R5L | Angle type |
| Protective cover | SSP-BF205 | Protective cover:1 |
| | SSP-BF210 | |
| Reflector | S-SSP120 | Adhesive tape on the back side cuttable |
| | S-SSP245 | |
| Mounting bracket | SSP-BR1 | Mounting brackets a set of two brackets |
| | SSP-BR2 | |

Applications



Rating/Performance/Specification

| Type | Attached cable | | SSP-S204R | SSP-S208R |
|----------------------------------|-------------------------------|---|---|--|
| | Attached cable with connector | | SSP-S204R-PJ | SSP-S208R-PJ |
| Detecting distance | | Retro reflective : 2m or less Diffuse reflective: 700mm (White drawing paper 300mm × 300mm) 400mm (18% reflectivity gray card A4 size) | | |
| Number of beams | | 4 | | 8 |
| Detecting width | | 100mm | | 225mm |
| Power supply | | 12 - 24VDC±10% Ripple: 10% or less | | |
| Current consumption | | 80mA or less / DC12V 49mA or less / DC24V | | 92mA or less / DC12V 58mA or less / DC24V |
| Output mode | Control output | | NPN / PNP output selectable | |
| | Rating | NPN output | Sink current 50mA (30VDC) or less, residual voltage 2V or less | |
| | | PNP output | Source current 50mA (30VDC) or less, residual voltage 2V or less | |
| Operating mode | | Normal open/Normal close selectable | | |
| Job indicator | Input | | Non-contact or contact input | |
| | Operating voltage | | NPN 2V or less/ PNP 8V or more | |
| Response time | | 120ms or less | | |
| Light source | | Infrared LED (wave length: 640 nm) | | |
| Indicators | | Initial sensitivity setting indicator (green LED/orange LED) / Operating indicator (orange LED) Job indicator (green)/ Fault indicator (red LED) | | |
| Job indicator Fault indicator | | Flashing | | |
| Short circuit protection | | Provided | | |
| Material | | Enclosure: Aluminum, End caps: PBT with glass fiber, Lens : Polycarbonate | | |
| Wiring | Attached cable | | Outer diameter: ϕ 4.1 mm, 0.2mm ² × 4 cores, 2m (black) | |
| | Cable with connector | | Cable with M12 connector 0.3m (black) | |
| Auxiliary functions | | Automatic initialization function/ Automatic re-initialization function | | |
| Weight | Attached cable | | Approx. 110g | Approx. 170g |
| | Cable with connector | | Approx. 120g | Approx. 180g |
| Accessories | | Driver for switch operation, operation manual (mounting bracket and reflector are separately available). | | |

Detecting distance and detected object vary depending on the type of the connected reflectors.

The detecting distance is the range which you can set for the sensor. The sensor can detect an object even in the immediate area of the sensor.

Environmental Specifications

| | |
|-------------------------|--|
| Ambient light | 10,000 lx or less |
| Ambient temperature | -10 - +55°C (non-freezing) |
| storage temperature | -25~+70°C (non-freezing or non-condensing) |
| Ambient humidity | 35~85%RH (non-condensing) |
| Vibration | 10-55 Hz / 1.5 mm double amplitude / 2 hours each in 3 direction |
| Shock | 500 m/s ² / 3 times each in 3 directions |
| Protective structure | IP62 |
| Dielectric withstanding | 1,000 VAC for 1 minute |
| Insulation resistance | 500 VDC 20 M Ω or higher |


SSP-S200

Input/Output Circuit and Connection


With the mode selector switch, you can select for Job indicator input and NPN/PNP type Receiver output.

- Attached cable type

When NPN output is selected.




When PNP output is selected.




- Cable with connector type(-PJ)

When NPN output is selected.



When PNP output is selected.




Connector pin assignment of the cable with connector type(-PJ)



| Pin | Cable color | specifications |
|-----|-------------|---------------------|
| 1 | Brown | 12-24 VDC |
| 2 | White | Job indicator input |
| 3 | Blue | 0V |
| 4 | Black | Control output |

- Connection

In a case where NPN output is selected




- About Wiring

When expanding the wiring, use cables with 0.5 mm² or more. The length of expansion has to be 100m or shorter for the transmitter and the receiver each.

Colors shown in parentheses are lead colors of cables with connector (optional accessories, model: FAC-D4R2S, FAC-D4R2L, FAC-D4R5S, FAC-D4R5L).

Performance curves (typical)

- Minimum diameter of detecting object in retroreflective type



Mode selector switch

- Before setting the mode selector switch, be sure to turn off the power.
- By setting slide switches inside the sensor, you can select the functions below.

1... Reflective mode

Select either Diffuse reflective mode or Retroreflective mode.
 DIFFUSE: Diffuse reflective
 RETRO : Retroreflective

2... Automatic sensitivity resetting

Select whether Automatic sensitivity resetting is activated.
 AUTO ADJ UST: Automatic sensitivity resetting is activated
 AUTO ADJ OFF: Automatic sensitivity resetting is NOT activated

3... Operation mode

Select output mode.
 N. O.: Normal Open
 Close when detecting an object
 N. C.: Normal Close
 Open when detecting an object

| | | | | |
|---|---------------------------------|-------------|---|--------------|
| 1 | Reflector mode | DIFFUSE | 1 | RETRO |
| 2 | Automatic sensitivity resetting | AUTO ADJUST | 2 | AUTO ADJ OFF |
| 3 | Operation mode | N.O. | 3 | N.C. |
| 4 | Fault indicator | F.L. ON | 4 | F.L. OFF |
| 5 | NPN/PNP output | PNP | 5 | NPN |
| 6 | frequency switch | FREQ. A | 6 | FREQ. B |

4... Fault indicator

Select whether Fault indicator is activated.

5... NPN/PNP output

Select Job indicator input and output type.


6... Frequency switch

With the frequency switch, either A or B of different frequencies can be set.

Indicators



● Job indicator and Fault indicator



When the sensor detects an object while there is no Job indicator input, the red light of Fault indicator blinks.

● Operation indicator



Operation indicator: Orange LED

It lights up when the output is ON (Close).

Initial sensitivity setting indicator: Green/Orange LED

Green: Green LED turns on when teaching is completed.

Orange/ Green blinking: Orange and Green lights blink while teaching is being performed.

Initial sensitivity setting function

- Initial sensitivity setting function --- when turning on the power

When you turn on the power, the initial sensitivity setting function runs for about three seconds.

While the initial sensitivity setting function is running (about 3 seconds), the green and orange LED on the front of the sensor blinks. When the initial setting is completed, green LED turns on.

- Automatic sensitivity resetting function --- during operation (You can turn this feature on or off with a switch.)

When an object continues to be detected for a long time (about 20 seconds), which might occur due to dirt and dust on the lens or optical axis deviation, the automatic sensitivity resetting function runs and the optimal sensitivity is set again. Use the DIP switch to turn this feature on or off.


SSP-S200

Installation precautions

- The sensor has to face straight to the shelf surface, which is opposite to the sensor, or to a reflector. Attach the sensor firmly so that optical axes will not move due to vibration.
- Install the sensor, using M4 screws, and the tightening torque has to be 0.8 N·m or less. (Screws and the like are separately prepared.)

Install the sensor so that it is parallel to the surface opposite, a shelf board or a reflector, facing the shelf board or the reflector.

Use the sensor in Diffuse reflective mode when the detecting distance (L) is up to 400 mm. When it is 400 mm or more, Retroreflective mode should be used.



Dimensions (in mm)

Optional Parts

Mounting bracket

- There are two types of mounting brackets
- A set includes two brackets.
- Four sets of M4x12 SEMS screws with washers and nuts are included.

Cable with connector

Model: FAC-D4R2S (L:2m)
FAC-D4R5S (L:5m)

CAD


Model: FAC-D4R2L(L:2m)
FAC-D4R5L(L:5m)

Model: SSP-B1 Flat type

- Accessories
Screw: 4
Nut: 4
- Material
SUS

Model: SSP-B2 L-shape type

- Accessories
Screw: 4
Nut: 4
- Material
SUS




Mounting bracket

- There are two types of mounting brackets.
- A set includes two brackets.


Model:
SSP-BR1

- Accessories
Screw: 4
Nut: 4
- Material
Resin (black)



Model:
SSP-BR2


- Accessories
Screw: 4
Nut: 4
- Material
Resin (black)



SSP-S200

Dimensions (in mm)


Model: SSP-S204R
SSP-S208R



Parts dimensions (in mm)

| Model | N | L1 | L2 | L3 |
|-----------|---|-----|-----|----|
| SSP-S204R | 4 | 130 | 140 | 21 |
| SSP-S208R | 8 | 255 | 265 | 30 |

Model: SSP-S204R-PJ
SSP-S208R-PJ




Parts dimensions (in mm)

| Model | N | L1 | L2 | L3 |
|--------------|---|-----|-----|----|
| SSP-S204R-PJ | 4 | 130 | 140 | 21 |
| SSP-S208R-PJ | 8 | 255 | 265 | 30 |


Optional Parts (separately sold items)

Model: S-SSP120
S-SSP245



| Model | L(mm) |
|----------|-------|
| S-SSP120 | 120 |
| S-SSP245 | 245 |


● Material Resin



Protective cover

Model: SSP-BF

● Material SUS



Parts dimensions (in mm)

| Model | L1 | L2 | L3 |
|-----------|-----|-----|-----|
| SSP-BF205 | 122 | 130 | 148 |
| SSP-BF210 | 247 | 255 | 273 |


Fore Correct Use



- Be sure to follow the instructions in the operation manual provided for correct use of the product.
- This sensor cannot be used as a power press safety device or other safety device to prevent death or injury that requires conformity to domestic or overseas standards or certification concerning protection of the human body. Use for such purposes may lead to death or serious injury.
- This designed to detect an object passing over a certain point or line.
- For safety applications, ensure safe operation of the detection and control system as a whole.

SSP-M32R

Polarized retroreflective bin-picking
Light curtain sensor



- Super thin body at only 12mm thick.

One-side wiring of the retroreflective type makes installation easier.

Space-saving sensors also remove obstacles from work.



- Easy-to-see large Job indicator

On the side of the body, there are large-sized, high intensity green LED Job indicators which are easy to see.

- Fault indicator

When the wrong item is taken from a shelf, red lights of the Fault indicator flash on and off, letting you know the item is wrong.

Type

| Detection method | Detecting distance | Detecting width | Set model | Number of beams | Operation mode | Output mode |
|---|---|-----------------|-----------------|-----------------|----------------|---------------------------|
|  Polarized retroreflective |  60~300mm (when using S-SSP70) | 40 mm | SSP-M32R | 2 | Dark ON | NPN open collector output |


The detecting distance and detection object varies, depending on reflector types combined with the sensor.

The detecting distance is the range which you can set for the sensor. The sensor can detect an object even in the immediate area of the sensor.

Optional Parts

| Type | Model |
|--------------------------------|-----------------|
| Reflector (supplied accessory) | S-SSP70 |
| Protective cover | SSP-BF32 |

Applications



Rating/Performance/Specification

| Model Name | | SSP-M32R |
|----------------------------------|---------|--|
| Detection method | | Polarized retroreflective |
| Detecting distance | | 60 - 300mm (S-SSP70 is used) |
| Number of beams | | 2 |
| Detecting width | | 40mm |
| Power supply | | 12 - 24VDC \pm 10% Ripple 10% or less |
| Current consumption | | 60mA or less |
| Output mode | | NPN open collector output, rating : sink current 100mA(DC30V) or less |
| Operating mode | | Dark on |
| Job indicator | Input | Contact or Non contact input |
| | Voltage | NPN: 2V or less |
| Response time | | 1ms or less |
| Light source(wave length) | | Red LED (630nm) |
| Indicators | | Job indicator (green LED), Fault indicator (red LED), Operation indicator (orange LED) |
| Job indicator Fault indicator | | Continuous lightning |
| Short circuit protection | | Provided |
| Material | | Case: ABS, Indicator window: polycarbonate, Optical window :acrylic |
| Connection | | Attached cable(outer diameter: ϕ 4 mm) 0.2mm ² x 4 cores, 2m, black |
| Weight | | Approx.60g(including cables) |
| Accessories | | Operation manual, reflector (S-SSP70) |

Detecting distances and detected objects vary depending on the type of the connected reflectors.
The detecting distance is the range which you can set for the sensor. The sensor can detect an object in the immediate area of the sensor.

Environmental Specifications

| | |
|-------------------------|--|
| Ambient light | 5,000 lx or less |
| Ambient temperature | -10 - +55°C (non- freezing) |
| Ambient humidity | 35 - 85%RH (non- condensing) |
| Vibration | 10-55 Hz / 1.5 mm double amplitude / 2 hours each in 3 direction |
| Shock | 500 m/s ² / 3 times each in 3 directions |
| Protective structure | IP40 |
| Dielectric withstanding | 1,000 VAC for 1 minute |
| Insulation resistance | 500 VDC 20 M Ω or higher |

• Applicable power supply unit


PS Series
High capacity of 200 mA at 12 VDC



(General-purpose type) PS3N
PS3N-SR
(Multifunctional type)PS3F
PS3F-SR


SSP-M32R

Input/Output Circuit and Connection




- The output transistor will turn off if a load short-circuit or overload occurs.
- Check the load state before restarting.

About Installation




- Install the sensor, using M4 screws and M4 nuts, and the tightening torque has to be 0.8 N·m or less. (Screws and nuts are optional accessories.)


Indicators



- Job indicator and Fault indicator







- operation indicator







Performance curves (typical)

Response Curves: Tilt Angle



Response Curves: Detecting Position




SSP-M32R

Dimensions (in mm)

Main unit

Model: SSP-M32R


CAD



Reflector

Model: S-SSP70 (supplied accessory)

● Material Resin




Effective reflecting surface: 70×30mm
Mounting: Pasted: adhesive on back side


- Optional Parts (separately sold item) ● Material Galvanized SPC (black)

Protective cover

Model: SSP-BF32



Protective cover attached



- Install the sensor, using M4 screws and M4 nuts, and the tightening torque has to be 0.8 N·m or less. (Screws and nuts are optional accessories.)

Fore Correct Use



- Be sure to follow the instructions in the operation manual provided for correct use of the product.
- This sensor cannot be used as a power press safety device or other safety device to prevent death or injury that requires conformity to domestic or overseas standards or certification concerning protection of the human body. Use for such purposes may lead to death or serious injury in the unlikely event of failure.
- This sensor is designed to detect an object passing over a certain point or line.
- For safety applications, ensure safe operation of the detection and control system as a whole.